

Refer to clutch roller replacement instructions in the service manual for your UTV.

Specific to HI-TORQUE ROLLERS Part #D-AC-IT-210-O:

Place the Tied (outer) pin through the casting, then through the washer and then through our roller with the **shiny face that has our logo** towards the washer.