

Refer to clutch roller replacement instructions in the appropriate service manual for your Ski-Doo snowmobile.

## Specific to HI-TORQUE ROLLERS Part #S-SD-HPV-003:

- Place the roller onto the stud with the **shiny face of the roller (that has our logo)** towards the stud head
- o Then proceed to place the OEM washer and then circlip on the stud after the roller